

S U M M I T A S C E N T - 1 TM



spireOSTM

O P E R A T I O N S M A N U A L



SUMMIT ASCENT-r™

spireOS™

OPERATIONS MANUAL

Version 1.0 | Spire Ranges © 2026

Our customers are the heroes who make our world, countries, and communities safer. At Spire, we create exceptional shooting range systems that prepare them for when duty calls.

OUR MISSION?

**EVERY HERO COMES
HOME SAFE.**



CONTENTS

SUMMIT ASCENT-r:

- INTRODUCTION 8
- WARRANTY 9
- BALLISTIC RATINGS 10
- LIMITATION OF LIABILITY 11

MASTER CONTROLS:

- NAVIGATION 14**
 - GENERAL NAVIGATION 15
- MANUAL SESSION 16**
 - OPERATIONAL CONTROLS 18
 - OPERATIONAL INDICATORS 19
- CONFIGURATION 20**
 - RANGE SETTINGS 21

OPTIONAL MOBILE CONTROLS:

- BROWSER ACCESS 23

TARGET COMPONENTS:

- PARTS LIST 25**
 - TARGET BILL OF MATERIALS 26
- ASCENT-r (STICK CLAMP) 31**
 - CENTERING WHEELS 32
 - DRIVE WHEELS / CABLE GRIPS 33
 - MOTOR HOUSING 34
 - MOTOR ASSEMBLY 35
 - DRIVE GEARS 36
 - RETURN PULLEY 37
 - RETURN PULLEY SPRING 38
 - TRACK ACCESSORIES 39
- CLAMPS 40**
 - STICK CLAMP 41
- MASTER CONTROL 42**
 - MASTER CONTROL CONSOLE BILL OF MATERIALS 43
 - MASTER CONTROL CONSOLE 44

MAINTENANCE:

- DAILY / MONTHLY / BIANNUALLY / YEARLY 47
- TOOLS 48**
 - LIST OF TOOLS NEEDED FOR MAINTENANCE 49
- RECOMMENDED REPLACEMENT PARTS 51**
 - REPLACEMENT PARTS LIST 52

SERVICE PLANS:

1 800 761 1231

CONTENTS

SERVICE PLANS 55

TROUBLESHOOTING:

- HMI TOUCH SCREEN 58
- TARGET UNITS 59
- PLC LED INDICATORS 60
- MOTOR LED INDICATORS 64
- PROX SENSOR LED INDICATORS 66
- PROX SENSOR LED INDICATORS 68
- POE INJECTOR LED INDICATORS 70
- ACCESS POINT LED INDICATORS 72

GLOSSARY:

- TERMS 76
- SYMBOLS 77

SUMMIT ASCENT-R INTRODUCTION

The Ascent-r is a motion-controlled, overhead, cable-driven target system that is ideal for any range’s customized training programs and courses of fire. Targets can be controlled individually, or synchronized with a Spire master control touch screen and/or app.

The Ascent-r system is outdoor-rated and proven durable, making it an ideal target system for all types of facilities and organizations; including law enforcement, military, government, commercial, private ranges, and indoor/outdoor ranges.

MASTER CONTROL CONSOLE OVERVIEW

The Master Control Console allows a range master to manually control drills for an individual position or for all of the positions simultaneously on the range. As an option, a phone app allows for the rangemaster to control the system from the firing line. Additionally, an optional wireless remote allows for the range master to control the system from the firing line.

IMPORTANT SAFETY INFORMATION



Maintenance and use must adhere to the guidelines in this manual. Improper use of any of the equipment can result in poor performance, product damage and even serious physical injury. Properly trained personnel should only operate the equipment within the range. For technical, mechanical and electrical maintenance, it is recommended that a trained professional be consulted. Protective headwear, eyewear and gloves should always be worn when performing any maintenance. Danger risks include, but are not limited to, electric shock, head injuries, limb or body crushing, poking/pinching of extremities and eye trauma.

Operators should take care when operating clamps and be aware of location of any sharp locations. Spire is not liable for any injuries sustained while operating the clamps.

WARRANTY OF EQUIPMENT

Refer to agreement documents for specific warranty details for your range. All Spire Ranges equipment is warranted against defects in materials or workmanship under normal use and service, with coverage periods varying by equipment type and range agreement. Warranty periods begin upon equipment handoff and completion of customer training and apply only to the original installation and purchaser.

Coverage excludes consumable items, normal wear and tear, misuse or abuse, improper maintenance, unauthorized modifications, non-approved materials, and damages caused by external factors, third-party systems, or alterations/repairs made by anyone who is not pre-authorized in writing by Spire Ranges to modify, alter, repair, or otherwise handle in any way the product. Damage resulting from the use of armor-piercing (AP) or tracer ammunition or calibers not approved for your range’s ballistic rating, as well as excessive wear from high-velocity rounds exceeding 3000 fps, is not covered.

Spire Ranges reserves the right to determine if any part is defective and to repair or replace parts as it elects. This warranty does not cover shipping costs of defective parts from the owner’s site. Customers are responsible for proper maintenance, maintaining service records, and timely reporting of issues. Return shipping to the site is covered by Spire Ranges during the warranty period. Warranty service is subject to compliance with required procedures, including remote troubleshooting prior to any authorized onsite service. This warranty covers on site labor, travel expenses and accommodations if applicable.

Damage of Spire Ranges equipment resulting in utilizing armor piercing (AP) ammunition or tracer rounds will not be covered under warranty. In addition, high velocity rounds (both ball and frangible) traveling at speeds more than 3000 fps may result in wear, dimpling and pocking of the 1/4” AR500 ballistic shields and target clamps depending on the angle of impact. Such wear, dimpling, and pocking under these conditions is not covered under warranty.

Spire Ranges provides lifetime phone and email support for troubleshooting and operational guidance. Extended warranties and service agreements are available separately.

BALLISTIC RATINGS

Ammunition specs listed below are examples of energy and velocity only. Note, any use of Armor Piercing (AP), Steel Core, or Tracer Rounds will void the warranty.

PLATE RATING	MUNITIONS TYPE	MAX ENERGY	MAX VELOCITY
1/4" AR500	Pistol	1175 ft-lbs	1485 fps
3/8" AR500	Pistol/Rifle	3600 ft-lbs	3300 fps

TYP. AMMO	BULLET WEIGHT	MAX ENERGY	MAX VELOCITY
.22 LR	40 gr HP	140 ft-lbs	1400 fps
9MM LUGER	124 gr FMJ	460 ft-lbs	1293 fps
.357 MAG	158 gr JSP	663 ft-lbs	1375 fps
.44 MAG	240 gr SWC	1175 ft-lbs	1485 fps
5.56X45MM NATO	55 gr FMJ	1402 ft-lbs	3388 fps
7.62X51MM NATO	150 gr FMJ	3048 ft-lbs	3025 fps
.308 WIN	150 gr SPTZ	2800 ft-lbs	2900 fps
30-06	180 gr SPTZ	3360 ft-lbs	2900 fps
300 WM	190 gr BTHP	3548 ft-lbs	2900 fps

Spire Ranges products can handle .50 BMG in moderation; however, due to the large amounts of energy exerted from the round, the following applies:

Repeatedly using .50 BMG will shorten the life expectancy of the product and may void warranty.

Repeated impacts of .50 BMG fired in the same location of the product can cause damage in as few as 50 rounds.


Any armor piercing (AP) rounds, particularly those from .50 BMG will void any warranty.

LIMITATION OF LIABILITY

Neither Spire Ranges, nor any company affiliated with it, makes any warranties, representations or promise as to the performance or quality of the product other than what is specified in the original agreement between Spire Ranges and the range Owner. The liability of Spire Ranges to the Owner for damages arising out of the manufacture, sale, delivery, use of resale of this product shall be limited to and shall not exceed the cost of repair or replacement of defective parts. Spire Ranges shall not be liable for loss of use, inconvenience or any other incidental, indirect or consequential damages.

No representative of Spire Ranges has the authority to make any representation or promise on behalf of Spire Ranges or to alter or modify the terms or limitations of warranties in any way.

NAVIGATION





Turner Manual Operation
Screen

Running Man Operation
p. 18

Courses of Fire Menu

Yard Line Lights
(optional)

Settings
p. 21



CONFIGURATION

SpireOS Version

Running Man Preset
Distances in Feet



OPTIONAL MOBILE CONTROLS:

- [1] Connect to the range WiFi.
 - WiFi: RangeAccess
 - Password: spireranges
- [2] Open a web browser.
- [3] Type spireos.home.arpa into the browser search bar and press enter.
 - If that doesn't work, try 192.168.1.20
- [4] The Operations Screen should load if everything is working correctly.

TARGET COMPONENTS:

PARTS LIST

CODE	DESCRIPTION	PRT #
1	CUBE HOMING PROX SENSOR**	EPX-NBN40-PF
2	1/4"-20 X 2" BUTTON HEAD SCREW - STAINLESS	HBH-25020-200-SS
3	***1/2" X 1-1/8" X 3/8" 2RS BALL BEARING	HBR-1616-2RS
4	***5MM X 22MM X 7MM (625-2RS) RUBBER SEALED BALL BEARING**	HBR-625-2RS-R
5	***1/2" X 1-1/8" X 5/16" (FR8-2RS) FLANGE BALL BEARING	HBR-FR8-2RS
6	M5 X 12MM TORX BOTTON HEAD SCREW - STAINLESS STEEL**	HBT-M5X12-SS
7	M6X10 BUTTON HEAD TORX SCREW - STAINLESS**	HBT-M6X10-SS
8	M6 X 12MM TAMPER RESISTANT BUTTON HEAD TORX SCREW	HBT-M6X12-TR-SS
9	M6 X 16MM TAMPER RESISTANT BUTTON HEAD TORX SCREW	HBT-M6X16-TR-SS
10	1/4"-20 X 1/16" CABLE GRIP**	HCG-25020-063
11	***460MM X 5M15 DRIVE GEAR BELT**	HDB-5M15-460
12	1/2" X 5M15 X 60T DRIVE GEAR WITH KEY	HDG-050-5M15-060-SPR
13	14MM X 5M15 X 20T DRIVE GEAR	HDG-5M15-14M
14	***1/4" X 3/8" X 3/8" FLANGE BEARING - BRONZE	HFB-250375-375
15	***FLANGE SLEEVE BEARING 3/8" ID	HFB-375500-500
16	1/4"-20 X 1/2" HEX HEAD BOLT - ZINC	HHB-25020-050-ZN
17	1/4"-20 X 3/4" HEX HEAD BOLT - ZINC	HHB-25020-075-ZN
18	1/4"-20 X 1-1/4" HEX HEAD BOLT - ZINC	HHB-25020-125-ZN

** Indicates recommended replacement parts. (See p. 120 for more information)
*** Indicated parts that are consumables and are not covered under the warranty agreement. In addition, any misuse, lack of maintenance, and/or modifications made to any Spire products will void all warrantees.



CODE	DESCRIPTION	PRT #
19	3/8"-16 X 6" HEX HEAD BOLT FULLY THREADED - STAINLESS STEEL	HHB-37516-600-SS
20	1" HOLE X 1/4" FLEX-GRIP LOCKING GROMMET	HLG-1000-025
21	#10-32 THIN NYLOCK NUT - ZINC	HLN-01032-001-ZN
22	1/4"-20 NYLOCK NUT - ZINC**	HLN-25020-005-ZN
23	3/8"-16 THIN NYLOCK NUT - ZINC	HLN-37516-001-ZN
24	5MM X 8MM UNDERSIZED MACHINE KEY - STAINLESS	HMK-5MMUB-8MM-SS
25	1/2" X 1" X 1-1/4" DISC BUMPER	HRB-50098-012
26	1/4" X 5/8" X #10-24 SHOULDER BOLT - STAINLESS STEEL	HSB-250063-1024-SS
27	1/2" X 1" X 3/8"-16 SHOULDER BOLT - STAINLESS STEEL	HSB-500100-37516-SS
28	MALE-FEMALE THREADED HEX STANDOFF**	HSO-M6-12MM
29	.935 OD X .187 WD X 4.50 X 305 LB/IN COMPRESSION SPRING	HSP-935187-450-CS
30	1-1/8" X .050" INTERNAL SPIRAL RETAINING RING	HSR-11305-050-PH
31	1/2" SHAFT EXTERNAL RETAINING RING	HSR-50002-EXT
32	1/4"-20 X 3/8" CUP SET SCREW STAINLESS STEEL	HSS-25020-038-SS
33	1/4" X 1/2" X 1/2" SPACER - ALUMINUM	HSW-250500-500-AL
34	1/2" X 3/4" X 1/8" SHIM - STAINLESS STEEL	HSW-50175-013-SS
35	1/4"-20 X 5/16" SLOT X 1/4" HEIGHT TEE NUT	HTN-25020-313-BP
36	#10 WASHER - STAINLESS STEEL	HWS-203438-1747-SS
37	.250 ID X OD .750 X .060 FLAT WASHER - ZINC	HWS-250750-060-ZN
38	.267 ID X .500 OD X .057 FLAT WASHER - STAINLESS STEEL	HWS-267500-057-SS



CODE	DESCRIPTION	PRT #
39	.375 ID X .812 OD X .062 FLAT WASHER - ZINC	HWS-375812-060-ZN
40	.500 ID X 1.060 OD X .070 FLAT WASHER - ZINC	HWS-5001060-070-ZN
41	M5 WASHER - STAINLESS STEEL**	HWS-M5X10-010-SS
42	TARGETRY DRIVE MOTOR - IP RATED**	MTR-DRV-IP65
43	RECON WHEEL HUB HOUSING	RCP-7325-111
44	ASCENT CARRIER BASE - POWDER COATED	TGP-140-002-PC
45	URBAN CARRIER SIDE COVER - POWDER COATED	TGP-140-007-PC
46	ASCENT CABLE HARNESS BRACKET - POWDER COATED	TGP-140-008-PC
47	ASCENT CARRIER CENTERING WHEEL BRACKET	TGP-140-011
48	ASCENT DRIVE PULLEY**	TGP-430-005
49	ASCENT TENSIONER PULLEY	TGP-430-006
50	RECON TENSIONER SHAFT	TGP-430-007
51	ASCENT PULLEY DRIVE SHAFT	TGP-430-009
52	ASCENT RUNNER MOTOR MOUNT PLATE	TGP-431-001
53	RUNNER MOTOR HOUSING SIDE PANEL	TGP-431-002
54	RUNNER MOTOR HOUSING TOP PANEL	TGP-431-003
55	RUNNER MOTOR HOUSING BOTTOM PANEL	TGP-431-004
56	RUNNER MOTOR HOUSING GAP PANEL	TGP-431-005



** Indicates recommended replacement parts. (See p. 52 for more information)



*** Indicated parts that are consumables and are not covered under the warranty agreement. In addition, any misuse, lack of maintenance, and/or modifications made to any Spire products will void all warrantees.

CODE	DESCRIPTION	PRT #
57	RUNNER MOTOR HOUSING CABLE COVER	TGP-431-006
58	ASCENT RUNNER GEAR COVER	TGP-431-007
59	ASCENT ADJUSTABLE RETURN PULLEY PLATE	TGP-610-001
60	ASCENT RETURN PULLEY SPRING ADJUSTMENT BRACKET	TGP-610-003
61	***ASCENT RETURN PULLEY SPRING GLIDE PLATE	TGP-610-004
62	ASCENT RETURN PULLEY SPRING BACKER PLATE	TGP-610-005
63	ASCENT RETURN PULLEY COVER	TGP-610-006
64	ASCENT REAR STOP WELDMENT - POWDER COATED	TGW-140-002-PC
65	ASCENT RETURN PULLEY SPRING PULL BRACKET	TGW-610-002
66	***RECON/URBAN END STOP BRACKET - LEFT	TKP-7040-151
67	***TRACK SPLIT HANGER BRACKET	TKP-7040-172
68	***ASCENT HOMING BRACKET - POWDER COATED	TKP-7040-186-PC
69	***URBAN RETURN PULLEY**	URP-7124-011
70	***ROLLER BLADE WHEEL ASSEMBLY	WHA-7010-001
71	***STICK TURNER CLAMP KIT	TGA-330-CLMP-STX
71.1	1/4" X 2-1/2" STEEL RING-GRIP QUICK-RELEASE PIN**	HRP-025-250
71.2	1/4"-20 X 3/4" SPADE THUMB SCREW - ZINC**	HST-25020-075-ZN
71.3	STICK TURNER BRACKET - POWDER COATED	TGP-330-001-PC
71.4	STICK TURNER CLAMP TUBE - POWDER COATED	TGP-330-005-PC










CLAMPS





MASTER CONTROL

CODE	DESCRIPTION	PRT #	QTY
1	15" HMI ENCLOSURE COVER - POWDER COATED	CTP-7915-231	1
2	15" HMI ENCLOSURE BACK PANEL - WAGO	CTP-7915-232	1
3	15" HMI ENCLOSURE MOUNTING BASE - WAGO	CTP-7915-233	1
4	1" X .030 GORILLA DOUBLE SIDED TAPE	DST-1000G-030	1
5	POWER INPUT SWITCH	ELE-2032-030	1
6	CAT-6 RJ45 BULKHEAD COUPLER	ELE-31C6-RJ45	1
7	24VDC 2.5A POWER SUPPLY - 60W	ELE-6024-060	1
8	15.6" HMI - WAGO WEB PANEL	ELE-65156-WWP	1
9	1/4"-20 X 5/8" BUTTON HEAD SCREW - BLACK OXIDE	HBH-25020-063-BK	6
10	.313 X .620 X .060 INSULATION WASHER - NYLON	HIW-313620-060-NY	2
11	1/4"-20 X 1/2" RETURN SPRING PLUNGER**	HRS-25020-050	1
12	5/16" X 5/16" X 1/4"-20 SHOULDER BOLT	HSB-313313-25020	2
13	.317 ID X .500 OD X .125 FLAT WASHER - NYLON	HWS-317500-125-NY	2

** Indicates recommended replacement parts. (See p. 52 for more information)

*** Indicated parts that are consumables and are not covered under the warranty agreement. In addition, any misuse, lack of maintenance, and/or modifications made to any Spire products will void all warranties.



POWER	VALUE
Power Consumption	24 VDC
Voltage	20.8 Watts Max

TEMPERATURE	VALUE
Operating	-20-55°C (-4-131°F)
Storage	-20-70°C (-4-158°F)

ROUTINE MAINTENANCE

TIME TABLE	PROCEDURE
Daily	1. Inspect the top of the track to ensure that no debris is jammed in it, or wedged between the track hanger and the track. Remove debris as necessary. 2. Inspect under the proximity sensor switch bracket and make sure that no debris is jammed in it. Remove debris as necessary.
Monthly	1. Check each screw on the clamp and shaft to ensure they have remained tight. If they are loose, add medium-strength Loctite and torque them to 80 in-lbs. 2. Inspect the top and bottom of the track for damage. Smooth out damage with hand tools as necessary. 3. Inspect track bolts. Tighten and replace as needed.
Biannually	1. Check surge protector inside main control box and replace if needed. 2. Inspect cable tension and tighten if needed. 3. Shut power off to the drive unit. Manually move the carrier to check how smoothly it moves down the track. Return the carrier to the home position and turn the drive unit back on. Replace wheels as necessary.
Yearly	1. Check all the screws and bolts on the unit and the mounting assembly have remained tight. If any are loose, add medium-strength Loctite and hand tighten. 2. With power off, check all wire connections are tight and not damaged. If they are loose, hand tighten them.
As needed	1. Replace the aircraft cable. 2. Replace gear belt when deteriorated/worn.

MAINTENANCE:

LIST OF TOOLS

- T-30 Torx Driver
- T-25 Torx Driver
- 7/16 Socket/Wrench
- 5/16 Allen Wrench
- Medium-Strength Thread Locker
- Mini Flathead Screwdriver
- #2 Phillips Screwdriver
- Multimeter

TOOLS

RECOMMENDED REPLACEMENT PARTS

DESCRIPTION	PRT #	QTY
HIDDEN CLAMP	TGA-300-CLMP-HD	1
EXPOSED AR-500 CLAMP	TGA-300-CLMP-EX	1
STICKS CLAMP	TGA-300-CLMP-STX	1
MOTOR***	MTR-DRV-STND-IP	1
PLC	ELE-6005-530	1
SURGE PROTECTOR MODULE	ELE-CITEL-MOD	1
AIRCRAFT CABLE 500FT	SAC-0116-500	1
RETURN PULLEY	URA-7100-102	1
MOTOR PULLEY	TGP-430-005	1
HOME SENSOR	EXP-NBN40-PF	1
TRACK BUMPERS x2	RBR-250150-1500	1
ASCENT-r HARDWARE REPLACEMENT KIT (Below items are included in kit)	PEAK-360-HARDWARE-KIT	1
MEDIUM-STRENGTH LOCTITE	THREADLOCK-MS-06ML	1
CABLE GRIP	HCG-25020-063	3
QUICK RELEASE PIN	HRP-025-250	2
WHEEL BUTTON SCREW	HBT-M5X12-SS	10
HOGAN HOUSE LID BUTTON SCREW	HBT-M6X10-SS	10
THUMB SCREW	HST-25020-075-ZN	2

*** Indicates parts that will need to be programmed for a specific lane. It is recommended for them to be purchased and to remain on Spire shelves where they can be programmed to a specific lane as needed.

DESCRIPTION	PRT #	QTY
PULLEY SET SCREW	HSS-25020-038-SS	5
GEAR SET SCREW	HSS-01032-019-BK	10
TRACK BRACKET HEX BOLT	HHB-25020-100-ZN	5
TRACK HEX BOLT	HHB-25020-050-ZN	10
TRACK THIN LOCKNUT	HLN-25020-001-ZN	15
CARRIER COVER STANDOFF	HSO-M6-12MM-ZN	2
RUBBER GUIDE WHEELS	HBR-625-2RS-R	4
GUIDE WHEEL SPACERS	HWS-M5X10-010-SS	10

SERVICE PLANS:

OVERVIEW

At the core of Spire Ranges is our commitment to keep our installed equipment in each range running at its optimum performance. To maintain that standard, below is a list of the different service package levels available to our clients. We look forward to providing your range with a quote that is unique to your range.

LEVEL	TRIPS PER YEAR	PARTS DISCOUNT
Bronze	1	0%
Silver	2	5%
Gold	4	10%

SERVICES OFFERED WITH EACH SITE VISIT:

- Provided Refresher Training
- Software Update/Reconfiguration
- Test all Motors, Valves, Cylinders, Lights, & Proximity Switches
- Target Clamp Inspection/Adjustment
- Check/Secure Electrical Connections
- Verify Proper Voltages
- Verify Controller(s) (HMIs/Computer) Functionality
- Assess Cable Tension & Adjust
- Assess Track Health & Tighten/Replace any Loose/Missing Hardware
- Verify Proper Charging of Targets
- Stall/Bench Inspection
- Trap Inspection
- Overall Range Health Inspection

Given below are possible causes and solutions for system problems. Within this section, you will find sequential steps that can be used to help troubleshoot a problem. If a problem persists after following these troubleshooting guidelines, please contact the Spire support team.


1.0 HMI TOUCH SCREENS (MASTER & LOCAL)

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
1.1 Dark Blank Screen	(1) No power supplied to HMI	(1) Check the power supply connection. (2) Check circuit breaker to see if tripped. (3) If problem persists, contact Spire for technical support.
1.2 Entire HMI Touch Screen Nonresponsive	(1) HMI error	(1) Cycle power to HMI.
	(2) HMI / PLC fault	(1) Cycle power to the PLC.
1.3 Communication error	(1) Ethernet (RJ45) cable unplugged or damaged	(1) Check all RJ45 connections in control panel. (2) Check RJ45 connection to screen. (3) Follow cable to ensure they are not smashed or damaged.
	(2) PLC error	(1) Cycle power to the PLC. (2) See section 6 for more information on PLC errors.
1.4 Max number of visualization clients reached	(1) Too many browsers are connected at once	(1) Up to 3 devices can be using the interface at one time. If a local/master touch screen is present, both will count as a device. Disconnect any device that is not needed/wanted. (2) Reload the webpage.
	(2) PLC error	(1) Cycle power to the PLC.

2.0 ASCENT TARGET UNITS

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
2.0 Target continues to home	(1) Homing sensor misalignment	(1) Loosen two adjustment bolts on homing sensor. (2) Adjust homing sensor in/out and twist closer/further to the carrier.
	(2) Homing sensor malfunction	(1) See section 9.0 - 9.1.
2.1 Individual nonresponsive target (not moving)	(1) Not homed	(1) On the runner operation screen, press the home button. Carrier should slowly move to home. (2) If the problem persists, cycle power to the range. Wait 5 min before turning back on.
	(2) Stuck at Home after homing	(1) Move the carrier slightly to get it unstuck. (2) For a more permanent solution, inspect carrier/track for what is holding it up. Rectify the problem and try operating again.
	(3) Obstruction in drive system	(1) Power off the target. (2) Check the track/wheels/belt for obstruction. (3) Remove obstruction if one is present.
	(4) Motor fault	(1) Contact Spire for technical support.
	(5) No power	(1) Check circuit breakers.
2.2 Target faulting at same location repeatedly	(1) Obstruction/damage to track	(1) Remove obstruction if one is present. (2) Repair/replace track if damaged.

PLC LED STATUS




PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
6.0 No SYS (Power) Light	(1) Bad power cable connection/damaged cable	(1) Inspect the PLC power cable (cable coming out of the bottom of the PLC in connector X4) for damage. (2) Ensure that the PSU in the control box has power and that no breakers are flipped.
	(2) Bad PLC	(1) Contact Spire for a replacement PLC.
6.1 Orange SYS Light	(1) Device is in startup/boot process	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.
	(2) Bad PLC	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.2 Orange Flashing SYS Light	(1) "Fix IP Address" mode (temporary setting until the next reboot due to RST button press)	(1) Connect to the device via the standard address (192.168.1.17) or restart the device to restore the original value set.
	(2) Bad PLC	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.3 Green/Red Flashing SYS Light	(1) Firmware update mode	(1) Wait 30 min and check again. (2) If it continues to stay in this state, contact Spire.
	(2) Bad PLC	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.4 Green Flashing RUN Light	(1) No application and now boot project loaded	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.5 Red RUN Light	(1) Applications loaded and all in the "STOP" status	(1) Set the mode selector switch to "RUN" to start the application
6.6 Green/Red Flashing RUN Light	(1) At least one application in the "RUN" status and one in the "STOP" status	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.7 Red (goes out briefly) RUN Light	(1) Warm start reset completed	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.
6.8 Red (goes out longer) RUN Light	(1) Cold start reset completed	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
6.9 Red Flashing RUN Light	(1) At least one application after in the "STOP" status after exception (e.g., memory access error)	(1) Start the application with a reset via the mode selector switch. (2) Power cycle the controller. (3) Contact Spire for a replacement PLC.
6.10 Orange/Green Flashing RUN Light	(1) Load above threshold value 1	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.11 Orange RUN Light	(1) Runtime system in debug state (break-point, single step, individual cycle)	(1) Start the application with a reset via the mode selector switch (hold in reset position for 5 seconds then move back to RUN position). (2) Power cycle the controller. (3) Contact Spire for a replacement PLC.
6.12 No RUN Light	(1) No runtime system loaded	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.13 No Green LNK ACT 1 (Ethernet Status) Light	(1) Bad/damaged ethernet cable	(1) Replace ethernet cable.
	(2) Bad/damaged ethernet switch	(1) Swap PLC ethernet cable to another port on the switch.
	(3) Bad PLC	(1) Contact Spire for a replacement PLC.
6.14 No mSD Light	(1) No memory card access	(1) Some ranges may not have a micro SD card. If this is the case, then disregard the missing light.
6.15 No CAN Light	(1) The CAN interface has not been configured	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.16 Alternating red 50 ms / green 50 ms CAN Light	(1) Configuration in progress	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.
6.17 Alternating red 200 ms / green 200 ms CAN Light	(1) Configuration invalid	(1) Power cycle the controller. (2) Contact Spire for a replacement PLC.
6.18 Green 200 ms / off 800 ms CAN Light	(1) The CANopen interface has the status "Stop"	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.
6.19 Green 200 ms / off 200 ms CAN Light	(1) The CANopen interface has the status "Preoperational"	(1) Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
6.20 Red CAN Light	(1) The CANopen interface has the status "Bus Off" (short-circuit or other major fault)	(1) Check the CANbus connections (comms cable). Wait 5 min and check again. (2) If it continues to stay in this state, power cycle the controller.
6.21 No DO1 Light	(1) No Headless Wientek in system	(1) Some systems do not have a headless wientek. If this is the case, ignore this.
	(2) Runtime not fully loaded	(1) See 6.4 - 6.12.

MOTOR LED STATUS



PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
7.0 No Light	(1) Bad power cable connection/damaged cable	(1) Inspect the motor power cable (X3) for damage. (2) Ensure that the PSU has power and that no breakers are flipped.
	(2) Bad motor	(1) Contact Spire for a replacement motor.
7.1 Blinking Green Light (1sec interval)	(1) Device is operating normally	(1) N/A
7.2 One On, One Off Green Light	(1) General error	(1) Recalibrate the motor.
7.3 Two On, One Off Green Light	(1) Voltage error	(1) Check that capacitor is in place on the PSU and recalibrate the motor. (2) Ensure the PSU is supplying 48V DC to the motor.
7.4 Three On, One Off Green Light	(1) Temperature error	(1) Power down the system and let it cool down for 10-15 minutes.
7.5 Four On, One Off Green Light	(1) Overcurrent error	(1) Check that there are no debris in the clamp or motor housing.
7.6 Five On, One Off Green Light	(1) Controller error	(1) Power cycle the system. (2) Contact Spire for a replacement motor.
7.7 Six On, One Off Green Light	(1) Watchdog-Reset error	(1) See 6.0 - 6.20. (2) Contact Spire for a replacement motor.

CLAMP HOMING SENSOR LED STATUS



PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
9.0 No Green Light	(1) Bad cable connection/damaged cable	(1) Inspect the cable for damage. (2) Ensure that the PSU has power and that no breakers are flipped. (3) Check wires going into the larger green motor connector. Ensure that all wires are seated fully inside the connector.
	(2) Bad PSU	(1) Contact Spire for a replacement PSU.
	(3) Bad sensor	(1) Contact Spire for a replacement sensor.
9.1 No Yellow Light	(1) Clamp homing bracket not detected	(1) Adjust the sensor position to be closer to the travel location of the clamp homing bracket. (2) Recalibrate the lane.
	(2) Bad cable connection/damaged cable	(1) Inspect the cable for damage. (2) Check wires going into the larger green motor connector. Ensure that all wires are seated fully inside the connector.
	(3) Bad sensor	(1) Place a piece of metal over the sensor area temporarily to determin if sensor is operational. If not detected, contact Spire for a replacement sensor.

SURGE PROTECTOR STATUS



Visual Fault Indicator

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
10.0 One visual Indicator is red	(1) Module has experienced a surge	(1) Replace module at owner's convenience.
10.1 Both visual Indicators are red	(1) Module has experienced multiple surges	(1) Not able to protect. Replace module immediately.


POE INJECTOR STATUS



LED Status Indicator




Standard Port



POE Port

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
11.0 Steady White Light	(1) Operating correctly	(1) No troubleshooting needed.
11.1 Blinking Light	(1) Bad wiring	(1) Double check wiring. (2) Replace RJ45 ends on both ends of the ethernet cable in the POE port. (3) If not solved, replace ethernet cable.
	(2) Bad POE Injector	(1) Replace POE Injector.
11.2 No Light (Off)	(1) Not receiving power	(1) Check wiring. (2) Check breaker.
	(2) Bad POE Injector	(1) Replace POE Injector.

ACCESS POINT (AP) STATUS



PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
12.0 Flashing White / Off Every 1/2s	(1) The device is initializing and booting up	(1) Wait 5 min. (2) If it does not resolve itself, contact Spire for a replacement.
12.1 Steady White	(1) AP had power event that caused it to lose it programming.	(1) Wait 5 min. (2) If it does not resolve itself, contact Spire for a replacement or a reprogramming.
12.2 Slow Flashing Blue	(1) The device is initializing and booting up	(1) Wait 5 min. (2) If it does not resolve itself, contact Spire for a replacement.
12.3 Blue and Flashing Off Every 5s	(1) The device is initializing and booting up	(1) Wait 5 min. (2) If it does not resolve itself, contact Spire for a replacement.
12.4 Steady Blue	(1) Operating correctly	(1) No troubleshooting needed.
12.5 Strobing White / Off	(1) Internal error	(1) Power cycle the AP. (2) If it does not resolve itself, contact Spire for a replacement.
12.6 Quickly Flashing White / Blue	(1) The device firmware is currently being upgraded - do not interrupt the process.	(1) Wait 15 min. (2) If it does not resolve itself, contact Spire for a replacement.
12.7 Blue and Flashing Off Every 5s	(1) Access Point has lost network connectivity and is searching for a wireless uplink.	(1) Check any and all ethernet cables between the AP and the router. (2) If it does not resolve itself, contact Spire for further troubleshooting.
12.8 Rapid Flashing Blue / Off	(1) The device "Locate" feature was activated in the UniFi Network application.	(1) Power cycle the AP. (2) If it does not resolve itself, contact Spire for a replacement.
12.9 Flashing White-Blue-Off	(1) The device is in TFTP mode.	(1) If this wasn't intentional, please ensure the device's reset button isn't jammed (it should click when pushed).
12.10 LED Off	(1) Bad power	(1) Verify the Power, POE, and Ethernet cables to troubleshoot.
	(2) Bad AP	(1) Contact Spire for a replacement.

TERM	DEFINITION
Calibration	Adjusting the various parts of the system precisely for their particular function.
Consumable Components	Products that are expected to wear out and that get used up throughout the lifetime of the product (will need to be replaced on a regular basis).
Course (of Fire)	The programmed set of actions for each shooting target.
Edge	The side of the shooting target (not face or back).
Error / Warning / Alarm	A minor problem with the system, but the system will still run.
Exposure Times	The amount of time the face (not the edge) will be positioned toward the shooter.
Fault	A major problem with the system. The system will not run.
HMI	A human-machine interface, which is a feature of any device that enables humans to engage and interact with machines. Common examples include touchscreens and keyboards.
Loctite	A brand of adhesives that is used to prevent loosening of metal fasteners caused by vibrations.
PLC	A programmable logic controller, which is a computer control system, that controls other devices based on various information available to it.
Range Master	The person in charge of any given session.
Stage	A step in the Course (of Fire).

SYMBOL	DEFINITION
	Power (On/Off).
	Ethernet LED. Will light steady when an active Ethernet connection is made and flash when there is activity.
	Signal Strength.
	Caution.
	Risk of Electrical Shock.
	Risk of Hot Surface.
	Grounding Point/Terminal.
	Ethernet POE Port. Do not plug non-POE powered devices into this port on the POE Injectors.



THE PINNACLE OF SHOOTING RANGES™